

IPefono Wall Mount



4 VERIFICATION

- 1. Press the call button.
- 2. Verify that the button light blinks.
- 3. Wait until the call is answered in the Control Center.
- 4. Check that the communication is established in both directions.

1 INSTALLATION

- Remove the back of the IPefono Wall Mount introducing the finger into the center hole and pulling it out.
- 2. Make 4 holes of diameter 4 on the wall with a drill and fix the previous piece with their washers and screws, according to Figure 1, passing the Ethernet and power cables through the central hole.




Figure 1



2 CONNECTIONS

- 1. Connect the Ethernet cable (RJ45) according to Figure 2.
- 2. Plug the power supply cable in the screw connector according to Figure 2, leaving positive power on the left.




Figure 2

- 3. Close the device, fitting the top first and then introducing the bottom (Figure 3).
- 4. Fix the device cover with the screw on the bottom.




Figure 3

3 CONFIGURATION

- Access the device using a Web browser by typing the address http://192.168.3.17
- 2. From the Network option, configure the gateway in the Router IP address parameter on the screen similar to Figure 4.




Figure 4

3. Inside the Address (0) option set the IP address and subnet mask on the screen similar to Figure 5 and click Save.

Host IP address 192.168.3.17 Local network mask 255.255.255.0

Figure 5

4. Select the reset option in the screen similar to Figure 6. This may take several seconds.

Configuration saved!

reset

continue

Figure 6

5. Press Home to return to the main menu.

IMPORTANT: You must restart the device to take effect the changes. If not successful step 4, you must restart the device using tools-reset device option.